


MODEL CB1850

SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



9/13/2010

SPOTNAILS MODEL CB1850

Ref No.	Part No.	Description	
01	P-70043	Exhaust Deflector	
02	P-64392	O-Ring	
03	P-60192	Cap	
04	P-24300	Screw	
◆	05	P-15199	Exhaust Seal
◆	06	P-64332	O-Ring
07	P-22167	Poppet Valve Guide	
◆	08	P-64393	O-Ring
◆	09	P-62072	Gasket
10	P-18226	Spring	
◆	11	P-64232	Poppet O-Ring
12	P-63039	Poppet Valve	
◆	13	P-64233	Piston Stop O-Ring
◆	14	P-64234	Cylinder Seal O-Ring
15	P-03071	Retaining Ring	
◆	16	P-64394	O-Ring
17	P-03072	Cylinder Spacer	
◆	18	P-64235	Cylinder O-Ring
19	P-05113	Cylinder	
◆	20	P-64395	Cylinder O-Ring
◆	21	P-64236	Piston O-Ring
22	AS-06076	Piston & Driver Assembly	
23	P-15121	Bumper	

Ref No.	Part No.	Description	
24	P-15124	Return Seal	
25	P-01264	Body	
26	P-32142	E-Ring	
27	P-64389	O Ring	
28	P-60175	End Cap	
29	P-18228	Spring	
30	P-07386	Step Pin	
31	P-53184	Safety	
32	P-08494	Wear Plate	
33	AS-10055	Front Plate Assembly	
34	P-07356	Pin	
35	P-07354	Pin	
◆	36	P-64434	O-Ring
37	AS-04041	Latch Assembly	
◆	38	P-64239	Valve Housing O-Ring
39	P-22168	Upper Valve Housing	
40	P-18336	Spring	
◆	41	P-64240	O-Ring
42	P-22169	Plunger	
◆	43	P-64421	O-Ring
44	P-22170	Lower Valve Housing	
◆	45	P-64241	O-Ring

Ref No.	Part No.	Description
46	P-18337	Spring
47	AS-21017	Sequential Fire Trigger Assy.
48	P-07234	Trigger Pin
49	AS-21006	Bump Fire Trigger Assy.
50	P-26126	Nut
51	P-24450	Screw
52	P-32211	Washer
53	P-13098	Bracket
54	P-24364	Screw
55	P-32144	Washer
56	P-24317	Screw
57	P-04081	Latch
58	P-12483	Magazine
59	P-09214	Pusher
60	P-18483	Spring Stem
61	P-18484	Spring
62	P-12484	Magazine Cover
63	P-07237	Pin
64	P-18485	Spring
65	P-04082	Latch Housing
66	P-32227	Washer
67	P-24304	Screw
68	P-07234	Pin

◆ Parts Included In AS-97320 O-Ring And Seal Kit